



Master BV400

schemat

www.master.sklep.pl

kontakt: www.master.sklep.pl/kontakt


MODEL BV 400 - 230 V / 50 Hz

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number:

Rev A - Mar. 2019



PARTS LIST

Pos.	Code NR	Description
	4034.480	2 WAY OUTLET
	4035.301	1 WAY OUTLET
2	4035.012	FRONT CRADLE
3	4035.006	LATERAL RIGHT PANEL
4	4035.004	LOWER PANEL
5	4035.008	LATERAL LEFT PANEL
6	4035.035	MIDDLE CHAMBER INSULATION
7	4035.094	THERMOSTAT BULB BRACKET
8	4033.410	BULB CLIP
9	4033.356	LIMIT THERMOSTAT
10	4035.021	COMBUSTION CHAMBER
11	4035.016	FRONT UPPER PANEL
12	4035.018	REMOVABLE PANEL
13	4035.173	REAR UPPER PANEL
14	4031.045	COOLING THERMOSTAT
15	4032.692	SPACER
16	4031.047	SAFETY THERMOSTAT
17	4035.058	PLASTIC OIL PIPE
18	4033.198	90° CONNECTION
19	4161.501	STRAIGHT CONNECTION
20	4035.261	MOTOR SUPPORT
21	4035.272	MOTOR SUPPORT GASKET
22	4035.269	MOTOR SUPPORT
23	4290.254	RUBBER RING
24	4035.268	FAN CASE
25	4035.267	HOUSING BLADE
26	4035.266	BOTTOM HOUSING PLATE
27	4035.273	COMBUSTION FAN
28	4035.046	FUEL PUMP
29	4035.050	COMBUSTION MOTOR
30	4035.049	ELECTROVALVE POWER CORD
31	4035.275	DAMPER REGULATION PLATE
32	4035.010	REAR CRADLE
33	4111.081	MOTOR COUPLING
34	4035.276	DAMPER BRACKET
35	4035.271	DAMPER REGULATION HANDLE
36	4035.222	CAPACITOR
37	403	

MODEL BV 400

UNIT 2

PARTS LIST

Pos.	Code NR	Description
51	4117.686	ELECTRODES BRACKET
52	4110.394	FIBER WASHER
53	4110.363	SCREW
54	4110.393	ELESTIC WASHER
55	4033.198	90° CONNECTION
56	4035.260	PHOTOCELL SENSOR
57	4035.259	REAR RING GASKET
58	4035.014	LOWER PANEL
59	4035.164	WIRE BRACKET
60	4160.646	RUBBER RING
61	4104.170	SCREWS CLIP
62	4032.704	TANK CAP
63	4201.185	FUEL TANK FILTER
64	4034.457	FUEL LEVEL GAUGE
65	4035.099	FUEL PIPE
66	4035.100	FUEL PIPE
68	4035.098	OIL PIPE
69	4034.210	PLASTIC HANDLE
70	4035.242	METAL HANDLE
71	4033.090	FUEL FILTER
72	4035.095	FUEL FILTER BRACKET
73	4034.378	STRAIGHT CONNECTION
74	4033.467	WHEELS AXLE
75	4034.211	WHEEL
76	4034.214	COTTER PIN
77	4034.213	WHEELS WASHER
78	4033.470	WHEELS SPACER
79	4035.111	CHASSIS FOOT
80	4035.108	COMPLETE CHASSIS
81	4034.458	FUEL LEVEL GAUGE PLASTIC CONNECTION
82	4031.068	STRAIGHT CONNECTION
83	4034.217	FUEL SUCTION PIPE
84	4035.168	PLASTIC CAP
85	4034.269	REGULATION STOPPER
86	4035.158	CHASSIS BRACKET
87	4035.104	FUEL TANK
88	4260.246	BREATHE VALVE
89	4100.810	PIPE CLIP
90	4104.147	RUBBER PIPE
91	4031.068	STRAIGHT CONNECTION
92	4100.192	90° CONNECTION
93	4100.810	RUBBER CLIP
94	4034.309	METAL RUBBER CLIP
95	4035.002	UPPER FRAME
96	4035.114	PLASTIC CAP

MODEL BV 400

UNIT 2

PARTS LIST

Pos.	Code NR	Description
100	4111.032	RELAY
101	4110.490	ELECTRODES WIRE
102	4033.771	TERMINAL BOX
103	4032.852	7 WAYS CONNECTION
104	4032.921	6 WAYS CONNECTION
105	4033.256	HIGH TENSION TRANSFORMER POWER CORD
106	4035.182	CONTROL PANEL COVER
107	4031.541	HIGH TENSION TRANSFORMER
108	4032.853	5 WAYS CONNECTION
109	4033.251	RUBBER TRANSPARENT CAP
110	4035.243	POWER SELECTOR
111	4161.057	POWER SWITCH
112	4160.353	FUSE
113	4035.084	CONTROL PANEL GASKET
114	4033.528	FUSE HOLDER
115	4160.638	POWER SWITCH COVER
116	4035.081	POWER CORD
117	4100.656	NUT
118	4150.528	STRAIN RELIEF
119	4035.086	CONTROL PANEL BRACKET
120	4162.970	REMOTE THERMOSTAT CAP
121	4161.400	REMOTE THERMOSTAT PLUG
122	4117.058	SUPPLY LED
123	4160.647	REMOTE THERMOSTAT SOCKET
124	4035.089	COMPONENTS BRACKET
125	4035.085	CONTROL PANEL LABEL
126	4035.088	PC-BOARD


MODEL BV 400 - 230 V / 50 Hz

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number: 11238008496
Until Serial Number:

Rev -- Feb. 2019



PARTS LIST

Pos.	Code NR	Description
	4034.480	2 WAY OUTLET
	403	

MODEL BV 400

UNIT 2

PARTS LIST

Pos.	Code NR	Description
51	4117.686	ELECTRODES BRACKET
52	4110.394	FIBER WASHER
53	4110.363	SCREW
54	4110.393	ELESTIC WASHER
55	4033.198	90° CONNECTION
56	4035.260	PHOTOCELL SENSOR
57	4035.259	REAR RING GASKET
58	4035.014	LOWER PANEL
59	4035.164	WIRE BRACKET
60	4160.646	RUBBER RING
61	4104.170	SCREWS CLIP
62	4032.704	TANK CAP
63	4201.185	FUEL TANK FILTER
64	4034.457	FUEL LEVEL GAUGE
65	4035.099	FUEL PIPE
66	4035.100	FUEL PIPE
67	4035.036	MOTOR SHAFT COUPLING
68	4035.098	OIL PIPE
69	4034.210	PLASTIC HANDLE
70	4035.242	METAL HANDLE
71	4033.090	FUEL FILTER
72	4035.095	FUEL FILTER BRACKET
73	4031.064	STRAIGHT CONNECTION
74	4033.467	WHEELS AXLE
75	4034.211	WHEEL
76	4034.214	COTTER PIN
77	4034.213	WHEELS WASHER
78	4033.470	WHEELS SPACER
79	4035.111	CHASSIS FOOT
80	4035.108	COMPLETE CHASSIS
81	4034.458	FUEL LEVEL GAUGE PLASTIC CONNECTION
82	4031.068	STRAIGHT CONNECTION
83	4034.217	FUEL SUCTION PIPE
84	4035.168	PLASTIC CAP
85	4034.269	REGULATION STOPPER
86	4035.186	CHASSIS BRACKET
87	4035.104	FUEL TANK
88	4260.246	BREATHE VALVE
89	4100.810	PIPE CLIP
90	4104.147	RUBBER PIPE
91	4031.068	STRAIGHT CONNECTION
92	4100.192	90° CONNECTION
93	4100.810	RUBBER CLIP
94	4034.309	METAL RUBBER CLIP
95	4035.002	UPPER FRAME
96	4035.114	PLASTIC CAP

MODEL BV 400

UNIT 2

PARTS LIST

Pos.	Code NR	Description
100	4111.032	RELAY
101	4110.490	ELECTRODES WIRE
102	4033.771	TERMINAL BOX
103	4032.852	7 WAYS CONNECTION
104	4032.921	6 WAYS CONNECTION
105	4033.256	HIGH TENSION TRANSFORMER POWER CORD
106	4035.182	CONTROL PANEL COVER
107	4031.541	HIGH TENSION TRANSFORMER
108	4032.853	5 WAYS CONNECTION
109	4033.251	RUBBER TRANSPARENT CAP
110	4035.243	POWER SELECTOR
111	4161.057	POWER SWITCH
112	4160.353	FUSE
113	4035.084	CONTROL PANEL GASKET
114	4033.528	FUSE HOLDER
115	4160.638	POWER SWITCH COVER
116	4035.081	POWER CORD
117	4100.656	NUT
118	4150.528	STRAIN RELIEF
119	4035.086	CONTROL PANEL BRACKET
120	4162.970	REMOTE THERMOSTAT CAP
121	4161.400	REMOTE THERMOSTAT PLUG
122	4117.058	SUPPLY LED
123	4160.647	REMOTE THERMOSTAT SOCKET
124	4035.089	COMPONENTS BRACKET
125	4035.085	CONTROL PANEL LABEL
126	4035.088	PC-BOARD

MASTER
www.master.sklep.pl

www.master.sklep.pl
kontakt: www.master.sklep.pl/kontakt