



**Master BV471SR**

**schemat**

**[www.master.sklep.pl](http://www.master.sklep.pl)**

**kontakt: [www.master.sklep.pl/kontakt](http://www.master.sklep.pl/kontakt)**


# MODEL BV 471SR

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number:


Rev -- Sep. 2019



# MODEL BV 471SR

UNIT 2

ILLUSTRATED PARTS BREAKDOWN



# MODEL BV 471SR

UNIT 3

PARTS LIST

| N° | CODE      | DESCRIPTION               |
|----|-----------|---------------------------|
| 1  | 4240.553  | 4 WAY OUTLET              |
|    | 4240.825  | 1 WAY OUTLET              |
| 2  | 4240.791  | HANDLE                    |
| 3  | 4111.057  | HANDLE CAP                |
| 4  | 4162.934  | BOX COVER HANDLE          |
| 5  | 4240.476  | TRANSPARENT CAP           |
| 6  | 4240.768  | BURNER BOX COVER          |
| 7  | 4240.772  | COVER CLAMP               |
| 8  | 4240..591 | BURNER STABILIZATOR       |
| 9  | 4240.777  | DOCUMENTS BRACKET         |
| 10 | 4614.001  | BURNER PLUG               |
| 11 | 4514.302  | BURNER                    |
| 12 | 4514.126  | BURNER METAL PLATE        |
| 13 | 4514.605  | BURNER INSULATION PLATE   |
| 14 | 4240.475  | RUBBER CAP                |
| 15 | 4240.770  | CONTROL BOX BRACKET       |
| 16 | 4031.581  | 90° CONNECTION            |
| 17 | 4240.766  | RIGHT SIDE BURNER PANEL   |
| 18 | 4240.273  | CABLE RUBBER PROTECTION   |
| 19 | 4240.761  | LOWER BURNER PANEL        |
| 20 | 4240.764  | LEFT SIDE BURNER PANEL    |
| 21 | 4240.759  | EXTERNAL BURNER PANEL     |
| 22 | 4240.763  | INSULATION BURNER PANEL   |
| 23 | 4240.717  | WIRE HOOK                 |
| 24 | 4117.757  | STRAIGHT CONNECTION       |
| 25 | 4240.590  | 90° CONNECTION            |
| 26 | 4033.090  | FUEL FILTER               |
| 27 | 4240.402  | FUEL FILTER PANEL         |
| 28 | 4034.378  | STRAIGHT CONNECTION       |
| 29 | 4034.257  | METAL CAP                 |
| 30 | 4240.816  | EXTERNAL SIDE PANEL       |
| 31 | 4240.496  | INTERNAL SIDE PANEL       |
| 32 | 4240.730  | REINFORCEMENT BRACKET     |
| 33 | 4240.465  | INTERNAL INSULATION PANEL |
| 34 | 4240.506  | INTERNAL UPPER BIG PANEL  |
| 35 | 4240.482  | EXTERNAL UPPER BIG PANEL  |
| 36 | 4240.513  | INTERNAL CHIMNEY PANEL    |
| 37 | 4240.480  | EXTERNAL CHIMNEY PANEL    |
| 38 | 4240.436  | REGULATION CHIMNEY PANEL  |
| 39 | 4240.501  | COMBUSTION CHAMBER        |
| 40 | 4514.105  | TURBULIZATOR              |
| 41 | 4240.477  | CHIMNEY CAP               |
| 42 | 4240.503  | EXTERNAL CHAMBER PANEL    |
| 43 | 4240.504  | INSULATION CHAMBER PANEL  |
| 44 | 4240.462  | EXTERNAL BACK PANEL       |
| 45 | 4240.499  | INTERNAL BACK PANEL       |
| 46 | 4240.505  | LIFTING BRACKET           |
| 47 | 4240.191  | CHASSIS CORNER            |
| 48 | 4240.453  | SMALL HORIZONTAL PROFILE  |
| 49 | 4240.798  | FRONT LEFT PROFILE        |
| 50 | 4240.796  | FRONT RIGHT PROFILE       |
| 51 | 4240.814  | LOWER LEFT PROFILE        |
| 52 | 4240.812  | LOWER RIGHT PROFILE       |
| 53 | 4240.444  | BACK LEFT PROFILE         |
| 54 | 4240.427  | BACK RIGHT PROFILE        |
| 55 | 4240.448  | UPPER LEFT PROFILE        |
| 56 | 4240.478  | UPPER RIGHT PROFILE       |

*PARTS LIST*

| <b>N°</b> | <b>CODE</b> | <b>DESCRIPTION</b>      |
|-----------|-------------|-------------------------|
| 57        | 4240.741    | INTERNAL MOTOR PANEL    |
| 58        | 4240.498    | MOTOR-FAN               |
| 59        | 4100.656    | NUT                     |
| 60        | 4150.528    | STRAIN RELIEF           |
| 61        | 4514.607    | WIRE PROTECTION         |
| 62        | 4510.855    | SENSOR CLIP             |
| 63        | 4240.438    | SENSOR BRACKET          |
| 64        | 4240.467    | CHAMBER SUPPORTING BEAM |
| 65        | 4240.494    | FOOT                    |
| 66        | 4240.486    | LOWER BIG PANEL         |
| 67        | 4240.488    | LOWER SMALL PANEL       |
| 68        | 4514.845    | WHEEL CLIP              |
| 69        | 4240.017    | WHEEL                   |
| 70        | 4240.424    | AXLE BRACKET            |
| 71        | 4240.019    | WHEELS AXLE             |
| 72        | 4240.407    | BURNER WIRE             |
| 73        | 4160.651    | STRAIN RELIEF           |
| 74        | 4160.648    | MOBILE COVER            |
| 75        | 4161.401    | MALE PLUG               |
| 76        | 4161.400    | FEMALE SOCKET           |
| 77        | 4160.647    | 90° COVER               |
| 78        | 4162.970    | THERMOSTAT CAP          |
| 79        | 4240.577    | FUSE HOLDER             |
| 80        | 4117.057    | FUSE                    |
| 81        | 4240.413    | LATERAL LABEL           |
| 82        | 4033.905    | LIMIT THERMOSTAT CAP    |
| 83        | 4033.906    | LIMIT THERMOSTAT NUT    |
| 84        | 4240.290    | LIMIT THERMOSTAT        |
| 85        | 4100.656    | NUT                     |
| 86        | 4150.528    | STRAIN RELIEF           |
| 87        | 4260.288    | CAP                     |
| 88        | 4240.757    | METAL BOX               |
| 89        | 4240.406    | TEMPERATURE SENSOR      |
| 90        | 4240.758    | COMPONENTS BRACKET      |
| 91        | 4240.414    | SWITCH                  |
| 92        | 4240.599    | BYPASS SWITCH           |
| 93        | 4117.058    | LED                     |
| 94        | 4510.414    | TERMINAL BOX            |
| 95        | 4117.669    | MOBILE TERMINAL BOX     |
| 96        | 4240.13     |                         |



**www.master.sklep.pl**  
**kontakt: [www.master.sklep.pl/kontakt](http://www.master.sklep.pl/kontakt)**