




Master BF95

schemat

www.master.sklep.pl

kontakt: www.master.sklep.pl/kontakt

MODEL BF 95



Pos.	Code NR	Description	Q^ ty
1	S/R	Right side case	1
2	S/R	Left side case	1
3	S/R	Fore side case	1
4	S/R	Lower case bracket	1
5	S/R	Control panel	1
6	S/R	Bottom panel	1
7	S/R	Right panel	1
8	S/R	Left panel	1
9	4034.039	Burner panel	1
10	S/R	Upper fore panel	1
11	S/R	Upper fore bracket	1
12	S/R	Rear upper bracket	1
13	S/R	Rear panel	1
14	S/R	Fan baffle	1
15	4034.041	Fan frame	1
16	4034.042	Upper left flap	1
17	4034.044	Lower left flap	1
18	4034.046	Upper right flap	1
19	4034.048	Lower right flap	1
20	4034.050	Hot air main outlet	1
21	4034.052	Hot air side outlet	2
22	4034.017	Thermostat bracket	2
23	S/R	Heat exchanger	1
24	4034.054	Tank	1
25	4034.057	motor fan assembly DD 12-12	1
26	4034.022	Thermostat LS/1	1
27	4034.023	Thermostat TR/2 40°	1
28	4034.024	Thermostat TR/2 (room temperature)	1
29	4034.025	Handle	1
30	4034.026	Triangular case lock	1
31	4034.027	Triangular case nylon key	1
32	4034.028	Electric box	1
33	4034.029	Plate plug	1
34	4034.030	Commutator	1
35	4034.031	Green light	1
36	4034.032	Red light	1
37	4034.033	Orange light	1
38	4034.034	Oil filter	1
40	4034.036	Oil Burner Riello 40G 10S	1

S/R – parts on special request only

MASTER
www.master.sklep.pl

www.master.sklep.pl
kontakt: www.master.sklep.pl/kontakt