




Master WA33

schemat

www.master.sklep.pl

kontakt: www.master.sklep.pl/kontakt



Pos.	Code NR	Description
1	4506.644	Fan
2	4506.605	Blowing Flap
3	4506.636	Power Cord
4	4506.610	Combustion Chamber Cover
5	4506.616	Thermostat cover
6	4506.606	Combustion Chamber
7	4506.620	Control Panel
8	4506.612	PC Board Cover
9	4506.641	Thermostat
10	4506.611	Motor Cover
11	4506.626	Filler Cap
12	4506.604	Filler Filter
13	4506.639	Fuel Pump Motor
14	4506.645	Fuel Pump Bracket
15	4506.647	Fuel Tank Valve
16	4506.648	Fuel Tank
17	4506.642	Feed Tee
18	4506.643	Driving Shaft
19	4506.627	Fuel Pump
20	4506.603	Fuel Pump Filter
21	4506.638	Feed Tube
22	4506.623	Base (legs + guide bar)
23	4506.601	Fuel Tank Cover Deflector
24	4506.619	Fuel Tank Screen
25	4506.624	Combustion Chamber Base
26	4506.646	Overflow Protection
27	4506.609	Cast Iron Pan
28	4506.614	Fuel Tank Cover
29	4506.608	Microswitch
30	4506.621	Combustion Chamber Ring
31	4506.602	Combustion Chamber Deflector
32	4506.600	Combustion Chamber Cylinder
33	4506.625	Combustion Chamber Cover
34	4506.637	Draught Regulator
35	4506.617	Combustion Chamber Back Panel
36	4506.613	Fan Cover
37	4506.618	Fan Back Panel
38	4506.640	Thermostat STB
39	4506.615	Thermostat STB Cover
40	4506.622	PC Board
41	4506.607	Shovel
42	4506.629	Seal Wire Small
43	4506.628	Seal Wire Big
not shown	4506.630	Conductor 3X1 0,9M
not shown	4506.631	Conductor 3X1 1,2M
not shown	4506.632	Conductor 5X1 2,6M
not shown	4506.633	Filter Pump Rubber Fuel Line
not shown	4506.634	Overflow Rubber Fuel Line
not shown	4506.635	Feed Rubber Fuel Line

MASTER
www.master.sklep.pl

www.master.sklep.pl
kontakt: www.master.sklep.pl/kontakt