



**Master XL61**

**schemat**

**[www.master.sklep.pl](http://www.master.sklep.pl)**

**kontakt: [www.master.sklep.pl/kontakt](http://www.master.sklep.pl/kontakt)**


MODEL XL61 - 230 V / 50 Hz

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From serial number: 04736000475


Rev.- - Sept. 2016



# MODEL XL61 - 230 V / 50 Hz

UNIT 2

ILLUSTRATED PARTS BREAKDOWN



## UNIT 2

## *PARTS LIST*

*Rev. - - Sept. 2016*

| <b>POS.</b> | <b>Code NR</b> | <b>Description</b>   |
|-------------|----------------|----------------------|
| 1           | 4201.046       | PROTECTION GRILLE    |
| 2           | 4201.074       | GRILLE RING          |
| 3           | 4201.045       | RADIATION DISK       |
| 4           | 4201.038       | COMBUSTION CHAMBER   |
| 5           | 4201.021       | VARNISHED SHELL      |
| 6           | 4201.048       | HANDLE               |
| 7           | 4201.044       | INSULATION CILINDER  |
| 8           | 4201.032       | CERAMIC FIBER GASKET |
| 9           | 4201.139       | PAPER GASKET         |
| 10          | 4201.421       | BURNER PLATE         |
| 11          | 4              |                      |

## UNIT 3

## PARTS LIST

Rev. - - Sept. 2016

| POS. | Code NR  | Description                         |
|------|----------|-------------------------------------|
| 51   | 4162.467 | THERMOSTAT CAP                      |
| 52   | 4117.695 | THERMOSTAT WIRES                    |
| 53   | 4201.447 | DISPLAY LABEL                       |
| 54   | 4104.336 | SWITCH COVER                        |
| 55   | 4106.179 | SWITCH                              |
| 56   | 4201.289 | SWITCH WIRE                         |
| 57   | 4201.424 | DISPLAY BOARD                       |
| 58   | 4201.293 | DISPALY BOARD WIRES                 |
| 59   | 4201.427 | PC-BOARD                            |
| 60   | 4290.021 | SPACERS                             |
| 61   | 4201.079 | POWER CORD                          |
| 62   | 4260.002 | PUMP                                |
| 63   | 4201.297 | ANTI-TILT WIRES                     |
| 64   | 4201.027 | PC-BOARD SUPPORT                    |
| 65   | 4260.110 | ANTI-TILT SWITCH                    |
| 66   | 4290.003 | CABLE FEEDTHROUGH                   |
| 67   | 4290.003 | CABLE FEEDTHROUGH                   |
| 68   | 4201.135 | BURNER COMPONENTS BRACKET           |
| 69   | 4290.052 | CABLE FEEDTHROUGH                   |
| 70   | 4290.055 | CABLE FEEDTHROUGH                   |
| 71   | 4260.003 | COMBUSTION MOTOR                    |
| 72   | 4260.009 | HIGH TENSION TRANSFORMER POWER CORD |
| 73   | 4260.253 | HIGH TENSION TRANSFORMER            |
| 74   | 4201.089 | HIGH TENSION WIRES                  |
| 75   | 4201.330 | RESET WIRES                         |
| 76   | 4110.394 | FIBER WASHER                        |
| 77   | 4201.035 | ELECTRODES                          |
| 78   | 4110.393 | ELASTIC WASHER                      |
| 79   | 4160.601 | SCREW                               |
| 80   | 4260.233 | RESET SWITCH                        |
| 81   | 4201.327 | RESET SWITCH BRACKET                |
| 82   | 4290.052 | CABLE FEEDTHROUGH                   |
| 83   | 4201.260 | PHOTOCELL                           |
| 84   | 4201.259 | PHOTOCELL BRACKET                   |

## RECOMMENDED PARTS LIST

Rev. - - Sept. 2016

| POS. | Code NR  | Description         |
|------|----------|---------------------|
| 3    | 4201.045 | RADIATION DISK      |
| 4    | 4201.038 | COMBUSTION CHAMBER  |
| 7    | 4201.044 | INSULATION CILINDER |
| 11   | 4        |                     |

**MASTER**  
[www.master.sklep.pl](http://www.master.sklep.pl)

[www.master.sklep.pl](http://www.master.sklep.pl)  
kontakt: [www.master.sklep.pl/kontakt](http://www.master.sklep.pl/kontakt)