



Master BCF231AL

schemat

www.master.sklep.pl

kontakt: www.master.sklep.pl/kontakt


MODEL BCF 231AL

UNIT 1

ILLUSTRATED PARTS BREAKDOWN

From Serial Number : 14G38000001

Rev.- - Feb. 2019



MODEL BCF 231 AL

UNIT 2

PARTS LIST

Pos.	Code N°	Description
1	4140.823	TOP LID
2	4140.824	WATER DIFFUSER
3	4140.825	SIDE PANEL
4	4140.826	COOLING PAD
5	4140.838	WATER PIPE 5 WAY
6	4140.835	CORNER
7	4140.842	WATER PUMP
8	4140.845	DRAIN VALVE
9	4140.846	WATER LEVEL SENSOR
10	4140.199	INLET VALVE
11	4140.840	FAN
12	4140.830	OUTLET PANEL
13	4140.833	MOTOR
14	4140.844	MOTOR SUPPORT
15	4250.007	CONTROL BOX
16	4140.841	WATER PIPE
17	4250.006	CONTROL BOX BRACKET
18	4140.965	DEVICE CLOTH
19	4140.961	AIR FILTER (WITH MAGNET)
20	4141.093	WATER PIPE

RECOMMENDED SPARE PARTS

Pos.	Code N°	Description
4	4140.826	COOLING PAD
7	4140.842	WATER PUMP
9	4140.846	WATER LEVEL SENSOR
11	4140.840	FAN
13	4140.833	MOTOR
15	4250.007	CONTROL BOX
17	4250.006	REMOTE CONTROL
19	4140.961	AIR FILTER (WITH MAGNET)

MASTER
www.master.sklep.pl

www.master.sklep.pl
kontakt: www.master.sklep.pl/kontakt